



## Sport Court Rubber Underlay Installation

The photos below show how easy it is to install the rubber underlay:

- Roll out the underlay and cut it to fit with a good pair of scissors.
- Do not overlap the underlay between rows. It is OK to leave small gaps between each section.
- Use duct tape or masking tape every 4-5 feet between the seems to help prevent wrinkling as you walk on it while installing the tiles after.
- Cut smaller pieces to fill in large gaps around door areas or odd shapes.

